Wirelessly connect to projector via laptop / surface tablet

1. Download "EasyMP Network Projection" from Epson (https://ftp.epson.com/drivers/epson16189.exe)
2. Install the software
3. Open "EasyMP Network Projection"
4. It will prompt you to select a connection type, select "Advanced Connection Mode"
5. Check the box to set the selected Connection mode as default.

6. Click OK
   a. You may receive a popup relating to your firewall select "Yes" if that prompt appears
7. Make sure the projector is powered on and then select "Automatic search"
8. Select the desired projection then hit connect.
   a. You should now be connected wirelessly to the projector.